

HYDRASTAR XL

TE5EHXL1200

Taking control with the Hydrastar XL trailer brake actuator is easy as...

Plug the remote control in-cab commander into cigarette lighter socket. You can swap tow vehicles in seconds – simply unplug commander from one vehicle to another. Depending on the tow vehicles electronics, hard wiring the vehicle may be necessary.



KIT CONSISTS OF:


- Electric/Hydraulic Actuator
- In-cab Commander
- 20 amp sealed lead acid battery
- Plastic Battery Case
- Emergency Breakaway Switch
- Detailed Instruction Manual

Six variable load settings, trailer-mounted microprocessor accelerometer control.

12 volt only or multi-volt.

High output pump offers faster braking response reduced stop distances.

HOW IT WORKS



PART NO	MODEL	VOLTAGE	AMPS	PRESSURE	PERFORMANCE 0–1200psi (SINGLE AXLE)	NO. OF AXLES	DIMENSIONS –LxWxH
TE5EHXL1200	XL	12 volt*	3 max	0–1200psi	1.25 secs.	1, 2, 3	416mm x 137mm x 112mm

BRAKE CONTROLS & ACCESSORIES

XL IN CAB COMMANDER

TE5EHCLR

12 Volt In-Cab Commander

TE5EHCLR24

Multi-volt, 12v–24v In-Cab Commander. Works in conjunction with multi-volt converter.



HYDRASTAR MULTI VOLT CONVERTER

TE5EHXLVR

Turns Hydrastar XL and Electrastar into Multi Volt Brake Actuators

Voltage converter developed by CM Trailer Parts for use with Hydrastar XL on 12 - 24 volt vehicles.

Protected against volt surges, and reverse polarity. Waterproof and vibration proof.



HYDRASTAR XL MULTI VOLT KIT

TE5EHXL24

KIT CONSISTS OF:

- 1x Hydrastar XL Actuator 1200psi
- 1x Multivolt In-cab Commander
- 1x Multi volt converter module
- 1x Breakaway Kit (Battery, Battery Box and Breakaway Switch)

